

## Beeper Volume

This scan sheet will work for the following scanners


- Gryphon™ Imager
- Gryphon™ Laser
- Quickscan™ Imager
- Powerscan™ D7100 or BT7100

Scan any one of the barcodes below to change beeper volume, or to disable the beeper


Beeper Off



Beeper Volume = Low



Beeper Volume = Medium



Beeper Volume = High

