



Verizon Wireless Hotspot Setup

Step 1 Power on your Orbic Hotspot



Press and hold the “power” button for 5 seconds until the welcome logo is displayed on the Screen, and Wi-Fi is on.



Step 2 Connecting to your Orbic Hotspot

Your Wi-Fi Name (SSID) and Password can be found on your device display upon initial power up.

You can also find your Wi-Fi Name and Password any time you need. Just press the power/menu button when the display is on.




Step 3 Connecting to the Internet

Use your device to search for the wireless network connection with the Wi-Fi's SSID “Verizon-RC400L-XX” and click “Connect”.


Enter PASSWORD.

The Password can be found by going to the 2.4GHz WIFI info or 5GHz WIFI Info screen. The password is displayed next to the lock icon.



Need Help?

Call 1(800) 922-0204 for help setting up a Orbic device.



Common Problems

No Service Available

Press and hold the “power” button for 5 seconds until the welcome logo is displayed on the Screen, and Wi-Fi is on.

Screen does not display

Check that the battery is in properly. Make sure the battery is fully charged. Plug it into the AC charger for at least 1 hour.

Cannot connect to hotspot

Check signal strength has at least 1 bar and display shows type of network. Make sure Windows Wi-Fi is turned on.

Hotspot won't turn off

Press and hold the Power button for 5 seconds until display shows “Powering Off”

Need Help?

Call 1(800) 922-0204 for help setting up a Orbic device.